



Rowe Scientific PTY LTD

For accuracy and professionalism



ADELAIDE
08 8186 0523

rowesa@rowe.com.au

BRISBANE
07 3376 9411

roweql@rowe.com.au

MELBOURNE
03 8795 7771

rowevic@rowe.com.au

PERTH
08 9302 1911

rowewa@rowe.com.au

SYDNEY
02 9482 8433

rowensw@rowe.com.au

www.rowe.com.au

A pH CALIBRATION IS ONLY AS GOOD AS THE BUFFER USED. THAT'S WHY ROWE SCIENTIFIC INTRODUCED THE CONTAMINATION FREE BOTTLE.

Rowe Scientific have introduced into Australia pH buffers in dual compartment "contamination protection" bottles for the improvement of Australian chemistry.

Features and Benefits

- Separate sampling chamber reduces contamination.
- Small volume can be discarded once calibration is complete.
- Over use is reduced.
- Room to swirl buffer.
- Small volume can be reused by replacing lid.
- As used in European laboratories.



Rowe Code
CB3515

Rowe Code
CB3115

Rowe Code
CB2660

How to use the contamination free bottle:



Remove reservoir lid

Squeeze bottle to fill reservoir

Calibrate electrode

Pour out waste

All of our buffers are traceable to NBS (NIST) international standards.

Buffer also available in 1L, 5L and 20L containers

Proudly manufactured in Australia by Rowe Scientific Pty Ltd.